

FASTENER CHART

For proper installation of **Shadoe®Track**, Sure Drive USA® requires:

18 nails per **8'** length of **Shadoe®Track**

52 screws per **8'** length of **Shadoe®Track**

Please use the above amount to determine an accurate estimate of the quantity of fasteners you need for your deck.

The chart below allows for nails spaced every **6"** when fastening **Shadoe®Track** to joist and **3** screws per **6"** wide deck board.

16" o.c. Joist Spacing

COMMON DECK SIZE	# OF TRACK REQUIRED	RECOMMENDED 9N/52S PER TRACK	FASTENERS REQUIRED
10' x 10'	14	14 x 18 Nails	= 252 Nails
		14 x 52 Screws	= 728 Screws
12' x 16'	23	23 x 18 Nails	= 414 Nails
		23 x 52 Screws	= 1,196 Screws
12' x 24'	33	33 x 18 Nails	= 594 Nails
		33 x 52 Screws	= 1,716 Screws
16' x 30'	53	53 x 18 Nails	= 954 Nails
		53 x 52 Screws	= 2,756 Screws

24" o.c. Joist Spacing

10' x 10'	10	10 x 18 Nails	= 180 Nails
		10 x 52 Screws	= 520 Screws
12' x 16'	17	17 x 18 Nails	= 206 Nails
		17 x 52 Screws	= 884 Screws
12' x 24'	24	24 x 18 Nails	= 432 Nails
		24 x 52 Screws	= 1,248 Screws
16' x 30'	38	38 x 18 Nails	= 684 Nails
		38 x 52 Screws	= 1,976 Screws

Recommended Fasteners: #10 x 2" Double-Hot Dipped "Ring Shank" nails from Sure Drive
 #10 x 7/8" Rustguard Coated, Pan Head Screws for 5/4" decking
 #10 x 1 1/4" Rustguard Coated, Pan Head Screws for 2"x decking